





























MAZDA					
Ltr. 					
1,4 F6JA F6JB	50 kW (68 PS)	2	04/03→	04-10081-01 	70-41369-00 
1,6 Y601	80 kW (109 PS)	3 CD 3 DI TURBO	06/04→	04-10043-01 	70-41369-00 
2,0 RF-3F RF-4F	66-74 kW (90-101 PS)	PREMACY TD 323 626 DI 626 DITD	04/98-05/04	04-10182-01 	70-41369-00 
2,0 RF-4F	74 kW (101 PS)	PREMACY TD 323 TD	07/00-03/05	04-10106-01 	70-41369-00 

MAZDA					
Ltr. 	   				
2,0 RF5C	89 kW (121 PS)	6 DI	08/02-08/07	<b>04-10071-01</b> →02/05 	<b>70-41369-00</b> 
<b>[NEW]</b>				<b>04-10231-01</b> 03/05→ 	
2,0 RF5C	100 kW (136 PS)	MPV Di 6 DI	06/02-08/07	<b>04-10071-01</b> 	<b>70-41369-00</b> 
2,0 RF7J	81-105 kW (110-143 PS)	3 5 CD 6 6 DI	03/05→	<b>04-10231-01</b> 	<b>70-41369-00</b> 
<b>[NEW]</b>					

MAZDA



2,2 R2AA  
R2BF


92-136 kW  
(125-185 PS) 6  
6 D

01/09→

04-10231-01

70-41369-00

[NEW]



2,5 MD25TI

80 kW  
(109 PS)

B-SERIE TD

06/99-07/06

04-10176-01

70-41369-00

